


**KitchenAid®****OVEN PARTS**

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)

27" BUILT-IN ELECTRIC  
DOUBLE OVEN  
THERMAL CONVECTION LOWER  
MICROWAVE CONVECTION UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	4	4448520	Bumper, Door	27		Liner, Oven
	8300653	Installation Instructions	5	4452490	Spacer, Foam			(Not serviceable)
	4456573	Use & Care Guide (Oven)	6		Screw	29	4455636	Sensor
	8300890	Use & Care Guide (Microwave)		8281236	Black	30	4449845	Bracket, Support
	4450786	Cooking Guide (Lable)		4449041	White	33	9760676	Deflector, Vent
	4449066	Cookbook (T/C Oven)	7	4455864	Top Chassis	34	4451666	Vent, Center
	8303852	Tech Sheet (Oven)	8	4449809	Screw	35	3400832	Screw
	4449264	Easy Set Guide (Oven)	9	4452158	Tube, Vent	37	9759243	Thermostat (TOD) (Temp.) SPST
	4451052	Guide, Easy Use (Microwave)	10	4452163	Lens, Light	43	4455529	Base, Chassis
	3191638	Safer Cooking Tips	11	4448972	Oven Light Assy	49	4448933	Retainer, Gasket
	9759133	Safer Cooking Tips	12	4452164	Bulb, Light	50	4451747	Cover, Back
2		Trim, Side	13	4452336	Insulation, Bottom Vent	51		Trim, Bottom
	4455430	RH Black	14	4455611	Frame, Front		4455442	Black
	4455432	RH White	15	4455381	Gasket, Door		4455444	White
	4455434	RH Biscuit	16	9752759	Relay		4455446	Biscuit
	4452083	RH S.Steel	17	3196176	Screw		4455146	Stainless Steel
	4455431	LH Black	18	4449040	Screw	52	4451755	Chassis, Back
	4455433	LH White	19	4451477	Support, Insulation	53	4452492	Insulation, Convection Top
	4455435	LH Biscuit	20	4451605	Cap, Spacer	54	4452491	Insulation, Convection Grill
	4452084	S.Steel	21		Rail, Side			
3		Hinge Receiver		4450583	Right Side			
	4455605	Left Hand		4450584	Left Side			
	4455606	Right Hand	22	4449154	Screw			
			23	4449743	Screw			
			24	4450038	Screw			
			25	4455641	Side, Chassis (R.H. & L.H.)			
			26	4452233	Back, Chassis			


## FOLLOWING PARTS NOT ILLUSTRATED

### INSULATION

4449315 Insulation, Wrap  
4450364 Insulation, Back

# CONTROL PANEL PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	8302669 Black 8302673 White 8302671 Biscuit 8302659 Stainless Steel	Switch, Membrane
2	4452602 Black 4452603 White 4452973 Biscuit 4451790 Stainless Steel	Panel, Control
3	3400832	Screw
4	4452260	Spacer, Foam
5	8302346	Assy, Control
6	4449745	Screw
7	4451592	Filter
8	4451632	Bracket, Filter
9	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4457126	Door Liner
2	8300571	Hinge, Door
	8300572	R.Side
	9760575	L.Side(S.Stl Mdl)
	9760576	L.Side(S.Stl Mdl)
3	4449253	Glass, Inner
4	4451721	Insulation, Door
5	4457131	Retainer, Glass
6	4449809	Screw
7	9759224	Glass, Inner
8	4449743	Screw
9	3196184	Screw


Illus. No.	Part No.	DESCRIPTION
10	3400832	Screw
12	4455393	Black
	4455392	White
	4455394	Biscuit
	4452315	Stainless Steel
13	4452500	Black
	4452501	White
	4452870	Biscuit
	4452087	Stainless Steel
14	4455803	Right Hand
	4455804	Left Hand

Illus. No.	Part No.	DESCRIPTION
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
19	4457102	Shield, Heat
	4449809	Screw
21	4452325	Seal, Door Top
22	4457113	Shield, Heat (Btm)
23	4450863	Black
	4450864	White
	4452119	Biscuit
	4451432	S.Steel
24	9759227	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LATCH PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent-Top
3	4455177	Elbow, Vent-Bottom
4	8300791	Bracket, Combo Chassis
5	4451758	Seal, Foam
6	4449154	Screw (2)
7	4449809	Screw
9	4450407	Baffle, Rear
10	9759525	Latch, Motorized
11	4452003	Blower
12	4455191	Plate, Service

## IMPORTANT PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.


The U.S. Consumer Product Safety Commission warns against do – it – yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4456104	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448715	Rack, Oven
7	9759322	Pad, Rack
7	4452155	Element, Bake


Illus. No.	Part No.	DESCRIPTION
8	4448881	Nut, Hex
9	4451583	Convection Motor
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe

Illus. No.	Part No.	DESCRIPTION
14	4448948	Probe, Meat
15	4455036	Tray, Bake
17	4450039	Cover, Bake Tray
18	4449809	Screw
20	4452157	Element, Convection
21	4448418	Cover, Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND STIRRER PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND STIRRER PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	29	4375278	Motor, Blower	55	4375422	Sensor, Temp.
3	4375252	Rubber Ring	30	4375279	Thermostat	56	4375420	Insulation
4	4375038	Screw	31	4375423	Thermostat	57	4375419	Duct, Heater
5	4375314	Air Duct, Magnetron	32	4375281	Thermostat	58	4375416	Washer
6	4375253	Support, Tube	33	4375408	Q Tube Assembly	59	4375417	Element, Heater
7	4375421	Plug, Ceramic	34	4375438	Transformer	60	4375418	Fan
8	4375255	Bushing	35	4375406	Ring Turntable	61	4375429	Motor, Fan
9	4375256	Reflector	36	4375407	Shaft, Turntable	62		Left-Threaded Nut
10	4375257	Chamber, Reflector	39		Bracket, Hinge			Serviced With
12	4375450	Duct, Inlet		4375412	Left			Motor Item 61
13	4375316	Insulation, Switch		4375413	Right	63	4375430	Thermostat
14	4375322	Fan Wheel	42	4375331	Plate, Grill	64	4375431	Shield, Heat
15	4375317	Duct, Air	43	4375332	Bracket	65	4375432	Insulation
16	4375415	Block, Slide	44	4375441	Cap, Fan	66	4375433	Chamber, Heat
17	4375248	Cover Plate, Upper	46		Switch Holder			Cabinet
18	4375251	Screw		4375412	Left	67	4375437	Isolation Plate
19	4375318	Lens, Lamp		4375413	Right	68	4375338	Cover Plate
20	4375319	Spring	47	4375258	Nut	71		Side Plate
21	4375320	Reflector	48		Insulation		4375341	Left
23	4452220	Rack		4375409	Left Side		4375342	Right
24	4393536	Crisp Plate		4375410	Right Side	72	4455915	Turntable
25	4375436	Capacitor	49	4375411	Plate, Side-	73	4375346	Switch
26	4375424	Magnetron			Bottom	74	4375347	Motor, Turntable
27	4375321	Fuse	50	4375425	Valve	75	4375348	Lamp
28	4375231	Block, Fuse	51	4375428	Screw to Valve	76	4375349	Rectifier
			52	4375427	Thermoactuator			
			53	4375426	Air Bleed			
			54	4375439	Shield, Heat			
					Right			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# MICROWAVE COMPARTMENT PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
 (Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	4452551	Support Rails Right Side
	4452552	Left Side
2	4449809	Screw
3	4452547	Rear Channel
4	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4450377	Cover, Top
2	4448935	Baffle, Blower
3	4450920	Blower
4	4451789	Plate, Mounting Transformer
5	4452104	Transformer, (Lights)
6	8303844	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
9	112432	Nut
9	4454949	Holder, Fuse


Illus. No.	Part No.	DESCRIPTION
10	4454976	Fuse
11	4449868	Block, Terminal
12	4452559	Side, Combo
13	4456144	Vent, Control Panel
14	4451597	Side, Control Top
14	4451598	Right
14	4451598	Left
15	4452244	Back, Control
16	4450550	Cover, Top Rear
17	4448664	Clamp
18	4452366	Cover, Top Front

Illus. No.	Part No.	DESCRIPTION
19	4455038	Transformer, Control Panel
20	4452247	Plate, Cover
20	4449809	Screw (4)
21	4451934	Suppressor
22	313806	Screw (2)
23	4449809	Screw
24	3400080	Screw
25	4450038	Screw
26	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MICROWAVE DOOR PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	8303555	Frame, Door
3	4450038	Screw
4		Bracket, Mounting
	4449141	Right Side
	4449142	Left Side
5	4449083	Filler, Side
6		Handle, Door
	4452500	Black
	4452501	White
	4452870	Biscuit
	4452087	Stainless Steel

Illus. No.	Part No.	DESCRIPTION
7		Glass, Outer
	4452210	Black
	4452788	White
	4452994	Biscuit
	4452258	Stainless Steel
8	4449809	Screw
9	4452330	Bracket, Handle
10		Retainer, Glass-Clip
	4450863	Black
	4450864	White
11	4375339	Door, Plate

Illus. No.	Part No.	DESCRIPTION
12	4375414	Frame, Inner
13	4375330	Strap, Door
14	4375313	Screw
15		Hinge, Door
	4375323	Left
	4375324	Right
16	4452398	Spring, Torsion(LH)
17	3196184	Screw (4)
18	4452395	Spring, Torsion(RH)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KEMC378KBL03, KEMC378KWH03, KEMC378KBT03, KEMC378KSS03  
(Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black
	4392899	Biscuit

## PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black
	4392901	Biscuit

## ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## SPLICING WIRES--25FT.

### LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## FOLLOWING PARTS NOT ILLUSTRATED

	4378950	Filler Kit (BL)
	4378951	Filler Kit (WH)
	4378952	Filler Kit (AL)
	814381	Kit, Pin Hinge
	4448950	Screw, Installation

## WIRING HARNESS PARTS

	8301909	Harness, Latch
	8303838	Harness, Main Filter
	4449809	Screw
	8301923	Harness, Main
	4450831	Ground (M/W)
	4450800	Screw
	4449809	Screw
	4450950	Conduit, Combo
	4450800	Screw
	313438	Clip, Harness
	4452222	Spacer, Harness
	4454835	Tie, Cable
	4452400	Lead, Ground